



# Accessible Means Of Egress

UNITED STATES ACCESS BOARD



## **New ADA Standards**



DOJ's 2010 standards (mandatory as of March 15)



Americas eir Disabilites Ac and Achitectural Barriers Act Accessibility Guidelines eine 71, 2004

Based on the Board's ADA-ABA Guidelines (2004)



### **Standards**

- Department of Transportation's ADA Standards
- Federal Standards for the Architectural Barriers Act – General Services Administration, Department of Defense and US Postal Service

UNITED STATES ACCESS BOARD



### **ADA Standards**

#### 207 Accessible Means of Egress

207.1 General. Means of egress shall comply with section 1003.2.13 of the International Building Code (2000 edition and 2001 Supplement) or section 1007 of the International Building Code (2003 edition) (incorporated by reference, see "Referenced Standards" in Chapter 1).

UNITED STATES ACCESS BOARD



### **ADA Standards**

**EXCEPTIONS: 1.** Where means of egress are permitted by local building or life safety codes to share a common path of egress travel, *accessible means of egress* shall be permitted to share a common path of egress travel.

2. Areas of refuge shall not be required in detention and correctional facilities.



### **ADA Standards**

207.2 Platform Lifts. Standby power shall be provided for platform lifts permitted by section 1003.2.13.4 of the International Building Code (2000 edition and 2001 Supplement) or section 1007.5 of the International Building Code (2003 edition) (incorporated by reference, see "Referenced Standards" in Chapter 1) to serve as a part of an accessible means of egress.

UNITED STATES ACCESS BOARD



### **IBC Definitions**

"Means of Egress. A continuous and unobstructed path of vertical and horizontal egress travel from any occupied portion of a building or structure to a public way. A means of egress consists of three separate and distinct parts: the exit access, the exit and the exit discharge."

-International Building Code 2003 Edition © ICC 2002

UNITED STATES ACCESS BOARD



### **IBC Definitions**

"Exit Access. That portion of a means of egress that leads from any occupied portion of a building or structure to an exit."

-International Building Code 2003 Edition © ICC 2002



### **IBC Definitions**

"Exit. That portion of a means of egress system which is separated from other interior spaces of a building or structure by fire-resistance-rated construction and opening protectives as required to provide a protected path of egress travel between the exit access and the exit discharge."

-International Building Code 2003 Edition © ICC 2002

UNITED STATES ACCESS BOARD



### **IBC Definitions**

"Exit. Exits include exterior exit doors at ground level, exit enclosures, exit passageways, exterior exit stairs, exterior exit ramps and horizontal exits."

-International Building Code 2003 Edition © ICC 2002

UNITED STATES ACCESS BOARD



### **IBC Definitions**

"Exit Discharge. That portion of a means of egress system between the termination of an exit and a public way."

-International Building Code 2003 Edition © ICC 2002



### **IBC Definitions**

"Accessible Means of Egress. A continuous and unobstructed way of egress travel from any point in a building or facility that provides an accessible route to an area of refuge, a horizontal exit or a public way."

-International Building Code 2003 Edition © ICC 2002

UNITED STATES ACCESS BOARD



### **New Construction**

The requirements for Accessible Means of Egress are a new construction requirement.

These requirements do not apply to alterations to existing facilities.

UNITED STATES ACCESS BOARD




### **Minimum Number**

At least one accessible means of egress is required from accessible spaces. (Spaces required to be on an accessible route.)

Where more than one means of egress is required, at least two accessible means of egress must be provided.



## At Least Two Means






## **Components**

- Accessible Routes
- Stairways within Exit Enclosures
- · (Areas of Refuge)
- Elevators
- Platform Lifts
- Horizontal Exits
- Smoke Barriers
- Exterior Area of Rescue Assistance

UNITED STATES ACCESS BOARD




## **Accessible Routes**





## **Stairways**



Exit Enclosure Stairways can Include Areas of Refuge

UNITED STATES ACCESS BOARD



## **Areas of Refuge**

- Smoke and fire protected areas usually provided in an exit enclosure
- Number of wheelchair spaces dependent on building occupancy loads
- Generally not required where an automated sprinkler system is provided

UNITED STATES ACCESS BOARD



## **Areas of Refuge**

Must have an accessible two-way communication system connected to a central control point





## **Areas of Refuge**


#### **Must Have Signage**



UNITED STATES ACCESS BOARD



### **Elevators**




Stand-by Power and Emergency Signaling Devices Required

Only used with the supervision of Fire Rescue Personnel

UNITED STATES ACCESS BOARD




## **Platform Lifts**





### **Horizontal Exits**



UNITED STATES ACCESS BOARD



# Exterior Area of Rescue Assistance

- Allowed when the Exit Discharge is not accessible
- · Similar to an Area of Refuge
- · Open to the outside
- No two-way communications required
- · Fire rated separation from the building

UNITED STATES ACCESS BOARD



## **Questions?**

U.S. Access Board	
144.47	
(800) 872-2253 (voice)	
(800) 993-2822 (TTY)	
E-mail: ta@access- board.gov	
www.access-board.gov	